

ULTRATOUGH[®] INSTALLATION

for MacBook[®]

WATCH THE INSTALLATION VIDEO

bodyguardz.com/install-clear-skins

Installation tools provided: Squeegee, cleaning cloth, application gel

PREPARATION

Turn your device off, wash your hands, and clean your device with provided cleaning cloth.

APPLICATION GEL

The gel allows you to easily position your protector while minimizing bubbles. Although it requires about 30 minutes to dry before use, there will be significantly less haze. Let your device sit overnight before putting it in a case or a bag, as it can take up to 72 hours to completely cure.

INSTALLATION TIPS

- Apply the wrist rest portions first to get a feel for the process, as they are the easiest pieces to install.
- When applying the bottom, use the back screw holes to properly align the protector.

QUESTIONS?

support@bodyguardz.com

1




Remove the film from the white back liner. Using your finger, spread application gel over the entire sticky side of the film.

2



Place the protector on the device, reposition by placing your fingers on the film and gliding it into the correct position.

3



Cover the squeegee card, or any credit card, with the provided cleaning cloth and press out from the middle to remove bubbles and excess gel.

4



Repeat process for all pieces of the protector.

5



Let sit for 30 minutes. Any haziness will disappear over time.

6



Learn more and register your product at: bodyguardz.com/advantage_program

BODYGUARDZ

THE ULTIMATE DEVICE PROTECTION[®]



@bodyguardz